

# Interop IP devices Messagenet

See below for a list with supported features when using the Gigaset PRO IP Devices on the providers network.

Feature	N870/N670 IP PRO	N510 IP PRO	N720 IP PRO	Maxwell 4	Maxwell Basic/2 /3
Gigaset software release used	2.23.0	42.250	113	3.14.8	3.14.8
Basic call	Yes	Yes	Yes	Yes	Yes
Calling line (CLIP)	Yes	Yes	Yes	Yes	Yes
Connected line (COLP)	No	No	No	No	No
Anonymous call	Yes	Yes	Yes	Yes	Yes
Do not disturb (DND)	Yes	No	No	Yes	Yes
Message waiting	No	No	No	No	No
Call list / history	Yes	Yes	Yes	Yes	Yes
Voice mail deposit / retrieval	No	No	No	No	No
Call waiting	Yes	Yes	Yes	Yes	Yes
Call hold / toggle	Yes	Yes	Yes	Yes	Yes
Call forward (CFU) (**21*Number#)	Yes	Yes	Yes	Yes	Yes
Call forward (CFNR) (**61* <number>#)	Yes	Yes	Yes	Yes	Yes
Call forward (CFB) (**67* <number>#)	Yes	Yes	Yes	Yes	Yes
Call transfer attended	No	No	No	No	No
Call transfer unattended	No	No	No	No	No
DTMF (RFC2833)	Yes	Yes	Yes	Yes	Yes
Conference 3pty	Yes	Yes	No	Yes	Yes
BLF busy / idle indication	NA	NA	NA	No	No
Call pick-up direct (*8 extension)	No	No	No	No	No
Call pick-up group (*8)	No	No	No	No	No
Call pick-up BLF	NA	NA	NA	No	No
Call completed elsewhere	No	No	No	No	No
Phonebook LDAP	No	No	No	No	No
Auto provisioning	No	No	No	No	No
Settings	<a href="#">Click here</a>	<a href="#">Click here</a>	<a href="#">Click here</a>	<a href="#">Click here</a>	<a href="#">Click here</a>

**ETSI codes:** see the following link for all ETSI codes used in case of call forward service: <https://helpcenter.messagenet.com/hc/it/articles/115010252187-Codici-ETSI-di-deviazione-di-chiamata>

**Provisioning:** is possible provision all generic parameters inserting, into the "Provisioning server" of each product, the URL indicated into the "Settings" field.

## How to:

- [N870/N670 IP PRO](#)
- [N510 IP PRO](#)
- [N720 IP PRO](#)
- [Maxwell 4](#)
- [Maxwell Basic/2/3](#)



