

FAQ Maxwell - Syslog

Introduction

Web-interface: **http://<IP address>/#/Expert**

Login as **admin** and switch to the above URL.

Valid for Maxwell

Basic

2

3

4

Syslog to Server

On setting the switch to "YES" you are able to configure a syslog server URL / IP address.
Per default the standard port "514" is used for the communication.
You can change the port by using is within the syslog server setting.

e.g. <http://192.168.0.90:520>

Sys Dump

For SysDump currently the download to the connected PC is supported, only. The download file is stored locally on the PC and can be send to Gigaset Support via Mail.

The SysDump file is password protected.

The screenshot shows the Gigaset Expert settings interface. On the left is a sidebar with menu items: SETTINGS (gear icon), STATUS (hamburger icon), and EXPERT (wrench icon). Under SETTINGS, there are links for Network, Audio, Debugging (highlighted in orange), Reboot, System Logging (highlighted in orange), Door Interphone, and Statistics. The main content area is titled 'Syslog to Server' and contains two settings: 'Activate syslog' with 'Yes' and 'No' radio buttons, and 'Syslog server' with a text input field containing '0'. Below this is a section titled 'Sys Dump' with a 'Send to PC' button (download icon). At the bottom right are 'Set' and 'Cancel' buttons. The Gigaset logo is in the top right corner.

Auto provisioning

Parameter	
System.Syslog.RemoteLogging.Enabled	Activate Remote Syslog 0 = Disabled 1 = Enabled
System.Syslog.RemoteLogging.Server	URL to the syslog server
System.Syslog.RemoteLogging.Server.Port	Syslog server port (514)