

Unify OpenScape 4000 V7

UCware

About OpenScape 4000

As part of the OpenScape Enterprise portfolio, OpenScape 4000 bridges the gap from legacy digital communications to IP-based unified communications. Both reside side-by-side in the same enterprise, on the same platform. You leverage and enhance your existing communications by introducing powerful state-of-the-art UC capabilities. But where needed, as needed.

Designed for enterprises from 300 to 12,000 users, OpenScape 4000 supports the full range of OpenScape UC for high-demand users, while allowing you to keep moderate-demand desks in digital format.

While mirroring the feature set and many of the same capabilities of our flagship OpenScape solution, OpenScape 4000 isn't the new kid on the block—it's been around and will stay around.

Flexible licensing means your users can move from one technology to the other as your needs demand. For data center deployments, it runs on industry-standard servers or as a traditional PBX platform. You need your communications ecosystem to do some heavy lifting? This just works.

See below for a list with supported features when using the Maxwell 10 version 1.2.7 behind the Openscape 4000 V7.



Feature	Maxwell 10
Software release:	1.2.7
Basic Call	Yes
Calling line (CLIP)	Yes
Connected line (COLP)	Yes
Anonymous call	No (PBX feature)
Do Not Disturb	Yes
Message waiting	NT
Call list/history	Yes
Voice mail deposit/retrieval	Yes
Call waiting	Yes
Call Hold / Toggle	Yes
Call forward (CFU)	Yes
Call forward (CFNR)	Yes
Call forward (CFB)	Yes
Call Transfer attended	Yes
Call Transfer unattended	Yes
Call Transfer blind	Yes
DTMF (RFC2833)	Yes
Conference 3pty	Yes (5pty)
BLF Busy / Idle indication	NT
Call pick-up direct	NT
Call pick-up group	NT
Call pick-up BLF	NT
Call completed elsewhere	NT
Videotelephony (h263)	Yes